

OMM Quick Release Mounted Rear Rack Installation Instructions

This rack is designed to mount on the outside of your bikes axle dropouts and fastened using our included longer quick-release skewer. The stock application mounts to the V-brake bosses over top of the V-brakes themselves. For bikes with no brake bosses or road caliper brakes we recommend using additional band clamps which will go around the fork legs.

This package includes:

- 2–Aluminum slotted extender bars
- 4–M6 x 16mm bolts
- 2–M6 x 20mm bolts for brake posts
- 4–M6 stainless nuts
- 10–Stainless washers
- 2–Aluminum angled brackets
- 1–Quick-release skewer

Necessary tools:

*4mm Allen wrench, and a
10mm open-ended wrench*



Remove your existing brake bolts. These hold the brake arm onto the frame (**do not remove or alter your brake arms or pads**).

Use supplied **20mm bolts** to bolt the angled brackets onto the brake studs (these bolts may replace the original brake bolts). The angle brackets will stick up above the bosses and brakes with the tab outboard from the wheel.

Use **16mm bolts** to attach the extender bar to the outside of the angled bracket using the single hole side leaving the slotted end to match up with the rack sidebar.

Now remove the quick release and place the rack over the axle dropouts. Insert the supplied quick-release skewer and, once the rack is level, tighten the skewer. With the remaining **16mm bolts**, attach extender bar to slot in rack (see picture).

